

Anleitung

Beier Distribution e.K.

Arrow Wraps

BY BEIER GERMANY®

www.bogensport-beier.de

Art.Nr.: 2722, 2723



1. Remove the foil carefull from the paper.




1. Quitare el folio del papel con cuidado.



2. Put the foil straight onto a soft surface, like a mousepad.

2. Coloque el folio con el lado adhesivo hacia arriba directamente sobre una superficie blanda.



3. Put the arrow shaft with mounted nock exactly and straight to the edge of the foil.

3. Coloque el tubo de la flecha con la leva montada en forma exacta y precisa en el borde de la lámina adhesiva.



4. Roll the arrow shaft gently and with a soft pressure over the foil.

4. Rodar el tubo de la flecha con una ligera presión sobre el folio.



5. Continue to roll the arrow shaft, till the shaft is completely enclosed by the foil.

5. El movimiento de rotación continuará hasta que el tubo está completamente cerrado.

